2026 Denmark
Starry 800L Light Set - English
Item # SL800WPWTW
Date: 08/24/2026

IMPORTANT SAFETY INSTRUCTIONS

When using electric products, basic precautions should always be followed including the following:

a) **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**
b) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
c) This seasonal-use product is not intended for permanent installation or use.
d) Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
e) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
f) Do not let LEDs rest on the supply cord or on any wire.
g) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
h) This is an electric product—not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
i) Do not use this product for other than its intended use.
j) Do not hang ornaments or other objects from cord, wire, or light string.
k) Do not place lighting string on carpeting, drapes, furniture, or allow it to contact vinyl siding while the power is on.
l) Do not perform any maintenance or troubleshoot for bad or broken LEDs while the power is on.
m) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
n) Do not cover the product with cloth, paper or any material not part of the product when in use.
o) To reduce the risk of fire and electric shock: a) do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal; and b) do not mount or support strings in a manner that can cut or damage wire insulation.
p) Read and follow all instructions that are on the product or provided with the product.

q) **SAVE THESE INSTRUCTIONS**

USE AND CARE INSTRUCTIONS

a) When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
b) If the product is placed on a tree, the tree should be well secured and stable.
c) Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the LED holders or enclosures, loose connections or exposed copper wire.
d) When storing the product, carefully remove the product from wherever it is placed, including tree branches, or bushes to avoid any undue strain or stress on the product conductors, connections, and wires.
e) When not in use, store neatly in a cool, dry location protected from sunlight.

AU26
FOR INDOOR AND OUTDOOR USE

CAUTION:

1. This lighting string is rated 31 Volt DC.

Do not replace or modify any con nectors on this product. Discard product if connector is damaged. Make sure connectors are fully inserted and any connector rings are twisted until completely secured such that the ring can no longer be turned and the two portions of the connector are comp letely assembled.

TIMER FEATURE:

HOW TO "SET" THE 6HR TIMER:

Press 1 time the button, it will light up green indicating that the timer is now activated.
Press 1 time the button, it will turn OFF indicating that the timer feature is now deactivated.

6”’’

10”

2026 Denmark
Starry 800L Light Set - Danmark
Item # SL800WPWTW
Date: 08/24/2026

VIGTIGE SIKKERHEDSINSTRUKTIONER

Ved brug af elektriske produkter skal grundlæggende forholdsregler altid følges, herunder følgende:

a) **LÆS OG FØLG ALLE SIKKERHEDSINSTRUKTIONER.**
b) Brug ikke sæsonbestemte produkter udendørs, medmindre de er mærket som egnet til både indendørs og udendørs brug. Når produkterne bruges udendørs, skal produktet tilsluttes en fejlstrømsafbryder (GFCI). Hvis der ikke medfølger en, skal du kontakte en kvalificeret elektriker for korrekt installation.
c) Dette produkt til sæsonbrug er ikke beregnet til permanent installation eller brug.
d) Må ikke monteres eller placeres i nærheden af gas- eller elektriske varmeapparater, pejse, stearinlys eller andre lignende varmekilder.
e) Produktets ledninger må ikke fastgøres med hæfteklammer eller søm, og de må ikke placeres på skarpe kroge eller søm.
f) Lad ikke LED'erne hvile på netledningen eller andre ledninger.
g) Tag stikket ud af produktet, når du forlader huset, når du går i seng for natten, eller hvis det efterlades uden opsyn.
h) Dette er et elektrisk produkt – ikke legetøj! For at undgå risiko for brand, forbrændinger, personskade og elektrisk stød, bør det ikke leges med eller placeres et sted, hvor små børn kan nå det.
i) Brug ikke dette produkt til andet end det tilsigtede formål.
j) Hæng ikke ornamenter eller andre genstande fra snor, ståltråd eller lyskæde.
k) Placer ikke lyskæde på tæpper, gardiner, møbler, og lad den ikke komme i kontakt med vinylbeklædning, mens strømmen er tændt.
l) Udfør ikke vedligeholdelse eller fejlfinding af defekte eller ødelagte LED'er, mens strømmen er tændt.
m) Luk ikke døre eller vinduer på produktet eller forlængerledninger, da dette kan beskadige ledningsisoleringen.
n) Dæk ikke produktet med stof, papir eller andet materiale, der ikke er en del af produktet, når det er i brug.
o) For at reducere risikoen for brand og elektrisk stød: a) må den ikke installeres på træer med nåle, blade eller grenbeklædning af metal eller materialer, der ligner metal; og b) må den ikke monteres eller understøttes på en måde, der kan skære eller beskadige ledningsisoleringen.
p) Læs og følg alle instruktioner, der findes på produktet eller følger med produktet.

q) **GEM DISSE INSTRUKTIONER**

BRUG OG PLEJEINSTRUKTIONER

a) Når produktet placeres på et levende træ, skal træet være velholdt og friskt. Placer det ikke på levende træer, hvor nålene er brune eller let knækker af. Hold træholderen fyldt med vand.
b) Hvis produktet placeres på et træ, skal træet være godt fastgjort og stabilt.
c) Inden brug eller genbrug skal produktet undersøges omhyggeligt. Kassér alle produkter, der har skåret, beskadiget eller flosset ledningsisolering eller ledninger, revner i LED-holdere eller -kabinetter, løse forbindelser eller blotlagte kobberledninger.
d) Ved opbevaring af produktet skal det forsigtigt fjernes fra den placering, det befinder sig i, inklusive fra trægrene eller buske, for at undgå unødig belastning eller stress på produktets ledere, forbindelser og ledninger.
e) Når den ikke er i brug, opbevares den pænt på et køligt, tørt sted beskyttet mod sollys.

FORSIGTIGHED:

AU26
TIL INDENDØRS OG UDENDØRS BRUG

1. Denne lyskæde er klassificeret til 31 volt jævnstrøm.
Udskift eller modificer ikke nogen stik på dette produkt. Kassér produktet, hvis stikket er beskadiget. Sørg for, at stikkene er sat helt i, og at eventuelle stikringe er drejet, indtil de er helt fastgjort, så ringen ikke længere kan drejes, og de to dele af stikket er fuldstændigt samlet.

TIMERFUNKTION:

SÅDAN "INDSTILLER" DU 6-TIMERS TIMEREN:
Tryk én gang på knappen, den lyser grønt, hvilket indikerer, at timeren nu er aktiveret.
Tryk én gang på knappen, den slukker, hvilket indikerer, at timerfunktionen nu er deaktiveret.

6”

10”