12.5”

STRIP LIGHT RINGING HOLIDAY BELLS

Please follow the instructions below in order to properly assemble and store your Strip Light Ringing Holiday Bells.

ASSEMBLY INSTRUCTIONS:

No tools required.
Retain carton for storage.

1. Carefully remove all parts from the carton, your Strip Light Ringing Holiday Bells should include the following (Fig 1):
   1 Completely assembled Ringing Holiday Bells
   1 Upper yard stake
   1 Lower yard stake
   1 Suction cup with hook attached



2. A yard stake is provided for ground application (Fig 5).
   Connect the lower yard stake into the upper yard stake (Fig 2a and 2b).



Insert the end of the upper yard stake into the designated slot area, located on the back (Fig 3).



AU26

3. A suction cup is provided for window application (Fig 4 and 6).



4. Place the Strip Light Ringing Holiday Bells in your desired location as shown in (Fig 5 and 6).



5. To illuminate, fully insert the plug into a working GFCI outlet or an outdoor rated extension cord.
   Your Strip Light Ringing Holiday Bells is now ready to either hang on any flat surface, or to be free-standing by the use of the yard stake provided.

TROUBLESHOOTING

1. Failure to light; unplug the product and check to see that the GFCI outlet is functioning.

STORAGE INSTRUCTIONS

1. Store in the original carton.
2. Store in cool, dry location away from sunlight.

Made in China
Printed in China
This is not a toy, for decorative use only.

12.5”

12.5”

AU26

LYSBÅND JULEKLOKKER
Følg nedenstående instruktioner for korrekt montering og opbevaring af dit Lysbånd – juleklokker.

MONTERINGSVEJLEDNING:
Ingen værktøjer påkrævet.
Gem emballagen til opbevaringsbrug.

1. Tag forsigtigt alle dele ud af emballagen.
   Pakken skal indeholde følgende (Fig. 1):
   1 komplet samlet Ringende juleklokker
   1 øvre jordspyd
   1 nedre jordspyd
   1 sugekop med påsat krog



2. Der medfølger et jordspyd til montering i jorden (Fig. 5).
   Saml det nedre og øvre jordspyd (Fig. 2a og 2b).



Sæt enden af det øvre jordspyd ind i det dertil beregnede hul på bagsiden (Fig. 3).



3. Der medfølger en sugekop til montering på vindue (Fig. 4 og 6).



4. Placér juleklokkerne på det ønskede sted som vist i (Fig. 5 og 6).



5. For at tænde skal stikket sættes helt i en fungerende GFCI-stikkontakt eller en udendørs godkendt forlængerledning. Dine juleklokker er nu klar til at blive ophængt på en plan overflade eller placeret frit ved hjælp af det medfølgende jordspyd.

FEJLFINDING
1. Hvis produktet ikke lyser, skal du tage stikket ud og kontrollere, at GFCI-stikkontakten fungerer.

OPBEVARING
1. Opbevar produktet i den originale emballage.
2. Opbevar det på et køligt og tørt sted, beskyttet mod sollys.

Fremstillet i Kina
Trykt i Kina
Dette er ikke et legetøj – kun til dekorativ brug.

12.5”